


Determination of directional echograms and application in room acoustics

J.J. Embrechts, N. Werner and F. Duthoit


Laboratory of Acoustics (Institut Montefiore ULg)




Echogram : definition



A diagram showing the distribution of the acoustical energy at the receiver, as a function of time arrival.
(whatever the direction of incidence)



Echogram : applications in room acoustics



Room acoustics
parameters :

-T30, EDT

- SPL

- C80, D50



- ...

auralization

Room impulse response





Directional Echogram : definition



A diagram showing the distribution of the acoustical energy at the receiver, as a function of time arrival, **in a particular direction of incidence.**

Directional echogram : computation




The directional echograms are evaluated by ray-tracing, at each listener's position.

The 3D space around the listener's head is divided into 26 solid angles, simulating 26 directional microphones.

Directional echograms : computation in two « academic » room acoustics problems

Example 1 : Room A (ref. Hodgson, JASA, 89(2), 1991)




Cubic room


-side length : 27.5m

-absorption coefficient
of all faces : 0.068

-scattering coefficient
of all faces : $d=0$ or $d=1$




Room A : Directional echograms at one receiver position,
5m away from the source, diffusing surfaces.




Room A : Directional echograms at one receiver position,
5m away from the source, specular surfaces.

direct



direct



Room A : Directional echograms at one receiver position,
5m away from the source.


Example 2 : Room B (ref. Hodgson, JASA, 89(2), 1991)


Long disproportionate room

-55m x 110m x 5.5m


-absorption coefficient
of all faces : 0.068

-scattering coefficient : $d=0$ or $d=1$






Room B : Directional echograms at one receiver position,
5m away from the source, diffusing surfaces.




Room B : Directional echograms at one receiver position, 5m away from the source, specular surfaces.


direct




direct



Room B : Directional echograms at one receiver position,
5m away from the source.




T30=16.4s




T30=4.3s

Room B : Energy decay curve at one receiver position,
5m away from the source.


RoomB, T30 directional (Horiz. plane) - Sphere no : 1, Freq : 500Hz




$d=0$



RoomB, T30 directional (Horiz. plane) - Sphere no : 1, Freq : 1000Hz



$d=1$



Room B : T30 directional at one receiver position,
5m away from the source.

Conclusion of the analysis of two « academic » problems

The directional echograms can afford interesting additional information, especially for :


- disproportionate rooms,
- weak diffusing surfaces,
- asymmetrical distribution of acoustical absorption.

Directional echograms : application in a room acoustics project

Project :

Renovation of an ancient horse-
riding school into a cultural
polyvalent hall.


Théâtre du Grand Manège
(Namur)



Plan Rez-de-chaussée
1/500^e


NOUVELLE COUPE FF

(COUPE BB) - 1/100e







absorbing roof




reflecting walls


Seats





Polyvalent hall, original situation :
Echogram and energy decay curve at one receiver position.



Polyvalent hall, original situation :
Directional echograms at one receiver position, 1 kHz.




Polyvalent hall, original situation :
Directional energy decays at one receiver position, 1 kHz.




Polyvalent hall, original situation :
Directional T30 at two receiver positions, 1 kHz.

Théâtre du Grand Manège (Namur)


First acoustical treatment :
Absorbent and diffusing surfaces on
the left wall
(when looking from the scene)



Polyvalent hall, first acoustical treatment :
Directional echograms at one receiver position, 1 kHz.



before treatment : $T_{30}=5.6s$






after treatment : $T_{30}=1.9s$

Polyvalent hall:
Directional energy decays at one receiver position, 1 kHz.


Théâtre du Grand Manège (Namur)

Horizontal audience surface






Polyvalent hall, horizontal audience surface :
 Echogram and energy decay curve at one receiver position.



tilted audience surface : $T30=1.9s$



horizontal audience : $T30=6.2s$

Polyvalent hall, horizontal audience surface :
Directional energy decays at one receiver position, 1 kHz.

Conclusions

- Directional echograms can give original information in non-diffuse acoustical fields.
- They are particularly useful in the detection of potential flutter echos, lack of diffusivity and asymmetrical distribution of absorption.
- They can explain significant differences between T30 and EDT, as a result of nonlinear energy decays.
- They can suggest optimal placement of absorbent and/or diffusing material to attenuate reverberation.